


Installation



Installation Instructions for models:

SLW3-90

SLW3-RD


SLW3-LxRx

IMPORTANT


- Read instructions entirely prior to installation.
- Prior to hooking up the fixture to the water supply make sure that all the lines are flushed thoroughly.
- All wall anchors should have a pull out strength of 1000 lbs or more.
- Units should always be installed according to local plumbing and/or electrical codes.

Installation


Top View



SLW3-90




SLW3-RD




SLW3-L15R15

(L15: Left wing is 15" – R15: Right wing is 15")


Front View



Model with skirt (-SK)





Model with drain cover (-DC)





Model without skirt or drain cover (-)

Installation

Side View – Mounted at Standard ADA Height




Juvenile Height Ages 6-12




Installation

TAS Height Grades Pre-K through 5 or 6




with skirt (-SK option)




with drain cover (-DC option)

TAS Height Grades 6 through 8 or 9




with skirt (-SK option)



with drain cover (-DC option)

Installation

Rough-in Dimensions SLW3 (No skirt or with Drain Cover Option)



* All vertical measurements are measured from the FINISHED floor

Code	Description
A	1/4" Anchors for support brackets with a pull out strength of min. 1000 lbs./
B	1/4" Anchors for (optional) drain cover
C	1/4" Anchors for corbels (only when unit has wings)
W	1 1/2" NPT Drain, stub out 2"
S	1/2" copper tubing for hot& cold supplies, stub out 2" from wall
R	110V GFCI outlet
TBD	Measurement depends on the length of the wings. We recommend no more than 2" from the end of the wing.


Height Adjustments

Standard	Rim Height Low Side	Adjustment of height for A, C, S, R & W
ADA & TAS Adult	34"	None
ADA Juvenile, Ages 6-12	31"	Subtract 3" to height in drawing
TAS, Grades 6 through 8 or 9	32"	Subtract 4" to height in drawing
TAS, Pre-K through Grades 5 or 6	30"	Subtract 2" from height in drawing

Installation



Rough-in Dimensions SLW3 (with Skirt option)




* All vertical measurements are measured from the FINISHED floor

Code	Description
A	1/4" Anchors for support brackets with a pull out strength of min. 1000 lbs./
C	1/4" Anchors for corbels (only when unit has wings)
W	1 1/2" NPT Drain, stub out 2"
S	1/2" copper tubing for hot& cold supplies, stub out 2" from wall
R	110V GFCI outlet
TBD	Measurement depends on the length of the wings. We recommend no more than 2" from the end of the wing.

Height Adjustments

Standard	Rim Height Low Side	Adjustment of height for A, C, S, R & W
ADA & TAS Adult	34"	None
ADA Juvenile, Ages 6-12	31"	Subtract 3" to height in drawing
TAS, Grades 6 through 8 or 9	32"	Subtract 4" to height in drawing
TAS, Pre-K through Grades 5 or 6	30"	Subtract 2" from height in drawing




Step 1: Rough-in


- a. When installing the fixture at non-standard height make sure to adjust the dimensions for height as shown on the table on page 5 or 6.
- b. Rough in the ½" copper supply tubing through the wall at the locations marked with **H** and **C** on the rough-in drawing on page 5 or 6.
- c. Rough in the 1 ½" drain connection through the wall at the location marked with **W** on the drawing on page 5 or 6.
- d. When using faucets with plug-in transformer(s): rough in the GFCI electrical outlet at the location marked with **R** on the drawing on page 5 or 6.
- e. When using a tankless water heater: rough in the electrical supply for the heater on the location shown on the drawing on page 5 or 6.
- f. Install eight 1/4" anchors on the locations marked with **A** on the drawing on page 5 or 6. The anchors should have a pull-out strength of 1000 lbs.
- g. Install four 3/8" anchors on the locations marked with **B** on the drawing on page 5. The anchors should have a pull-out strength of 1000 lbs.
- h. When corbels are supplied install these not more than 3" from the edge of the fixture.

Installation

Step 2: Installing the support brackets and bowl




- Install the mounting brackets to the wall
- Lift the deck on the brackets
- Attach the brackets to the deck by using the screws and washers provided



Installation

Step 3: Installing the P-trap



- a. Install the p-trap according to the picture below.



Step 4: Installing the drain cover or skirt

Draincover

- a. Install the drain cover under the sink by sliding it under the lavatory in the middle of the sink.
- b. Attach the drain cover directly to the wall.



Installation


Skirt

- Attach the bottom plate to the stainless steel skirt with the hardware provided.
- Attach the skirt to the support brackets with the hardware provided.
- Attach the skirt to the front of the lavatory with the hardware provided



Step 5: Installing corbels (-LxRx models only)

- Position the corbel under the side wing of the unit not farther than 3" from the edge of the fixture
- Mark the location on the wall where the corbel should be fastened.
- Install anchors in the walls with a pull-out strength of 1000 lbs at the marked locations.
- Anchor the corbels to the wall, make sure they fit snugly underneath the wing of the unit.



Maintenance

Solidsan[®] bowl and side panels

Solidsan[®] is a solid surface material made of acrylic modified polyester resins, aluminum trihydrate fillers and color granules. This synthetic compound material has an elegant granite-like appearance. Solidsan[®] is not only virtually indestructible and easy to maintain, but equally matches perfectly from an aesthetic viewpoint, this resulting in a remarkable design with soft, rounded shapes, ideal for the public washroom.

- Daily care: wipe the surface with soapy water or a damp cloth.
- Surface staining: clean the surface with soapy water or ammonia based cleansers.
- Stubborn stains and superficial scratches: clean the surface with an abrasive cleanser and a wet sponge. You can also use a green Scotch Brite[®] pad.
- Stubborn scratches: sand with 400 grit sandpaper and then clean with an abrasive cleanser and a green Scotch Brite[®] pad.
- AVOID contact with harsh chemicals such as drain cleansers and paint removers.
- AVOID contact with hot pots or heat producing appliances.

Stainless steel panels

Things to Avoid


- Avoid scouring a Stainless steel surface across the satin finish lines. Scouring across the satin finish lines can damage the original Stainless steel grain finish. Never use an abrasive scouring pad.
- Don't allow liquid soap or other household cleansers to dry on the Stainless steel surface. Most brands contain chemical additives, which will affect the finish.
- Never leave solutions of chlorine bleach and water on your Stainless steel surface for extended periods of time. Chlorides, which are found in most soaps, detergents, bleaches, and cleansers, are very aggressive to stainless steel. If left on too long they can cause surface pitting.
- Don't use a steel wool pad to clean your Stainless steel. Steel wool pads have a tendency to break apart and small particles of steel can become embedded in the surface of the sink. The steel particles will rust and will give the appearance that the Stainless steel itself is rusting.
- Never leave wet sponges, cloths, or cleaning pads on the Stainless steel surface. This can lead to surface rust.

Things to Do

- Rinse or clean surface after use. Clean with warm, soapy water.
- Avoid caustic chemicals. Avoid exposing your appliance to strong chemicals, such as paint removers, oven cleaners, etc. If contact occurs, quickly flush the surface with water.
- Follow the grain. When cleaning the Stainless steel surface of your sink, be sure to rub in the direction of the grain finish lines.

Installation


Parts Breakdown




SLW3RDBOWL + color




SLW390BOWL + color




SLW3LxxRxxBOWL + color




P453580 - Skirt 3-user
Streamlav Wing




P453590 - Bottom plate 3-user




P453000 - Right bracket for
unit with skirt




P453010 - Left bracket for
unit with skirt




P452510 - Right bracket
for unit without skirt



P452500 - Left bracket
for unit without skirt



SLWCORB + color -
Corbel



SLW3DC + color - Drain
Cover



P2770 - Spud



P453530 -Strainer
screen